

Outdoor CPE Router User Manual

Indicator status can tell the current device working status

indicator off

WiFi booting User connected

flash in 2s

1-bar signal(25%)

2-bar signal(50%)

3-bar signal(75%)

4-bar signal(100%)

Ethernet connection

Light on(flashing)

1.Click Start>Control Panel>Network and Internet>Network and

ation at

4G-CPE-XXXX

Ethernet input

Light on, flashing

indicator off

Non-ethernet input

Light off

Light on

Light on

Light on

Light on

No Ethernet connection

Power indicator

WAN/LAN

Green light

Signal indicato

Green

Network status

Sharing Center>Connect network

3.WiFi Connection

Windows 7

WiFi

ndicato


Blue

1. Brief Introduction

1) This product offers secure internet sharing service to multiple terminal users. WiFi devices(Smart phones, Tablets, PCs) can get access to internet through this device,enjoy 4G/3G/2G high speed services. The connection process depends on the system of each WiFi device, please follow the prompting messages.


a)et access to internet through ethernet cable. When getting access to internet through ethernet cable:

4G/3G/2G



b)Get access to internet through 4G/3G/2G Get access to internet by inserting SIM card and connecting to device.

4G/3G/2G



2.Choose the right SSID of the $\,$ 3. Type in the correct password and connect device, and click connect.



Type in network security key
security key
security key
'*******

'A' Hide character

4. Wait for a while till it is connected



Tip:Before connecting WiFi,please make sure the PC(or other devices) has the wireless network card,as shown on the image,click the wireless network list,if it shows the list,then the wireless network card works,otherwise you need to check your wireless network card.


Android Mobile phone

Setting, click WLAN, switch on WLAN
 Choose the right SSID





2. Product Introduction



Item	Introduction
WiFi Antenna	for WiFi signal receiving and sending
4G LTE Antenna	for 4G signal receiving
Power DC	12V-1A Connect and power on.
Micro USB port	for battery charging, firmware updating and outlet power supply by USB adapter, powerbank (only for emergency use)
WAN/LAN	for Ethernet cable input(WAN/LAN self-adaption)
SIM Slot	Standard SIM Slot(2FF)
Reset button	Long press for 5s to reset factory settings.

0:

3. Type in the correct password and connect.

4. Wait for a while till it is connected.



4G-CPE-XXXX

4.Backstage Configuration

Log in the WEB management interface

Please follow below steps to log in the management interface

- 1.Make sure the WiFi between the device and other wifi devices or PC are connected normally.
- 2.Open the browser, and type in [http://192.168.199.1] and enter.
- 3. Type in user name and password, log in the management interface, the default user name and password are both "admin".



03